




# Replace fan

Written By: Felice Suglia





## TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — accumulator



- Open the latch of the battery on the right side.
- Open the latch of the battery on the left side.
- Remove the battery.


## Step 2 — Access to the components 2



- Remove the Philips screwdriver to remove the two screws on the top cover.
- Check the markers to determine how the cover must be removed.
- Now remove the cover as required by the marker.





## Step 3




- The other components of the laptop are now visible.

## Step 4 — Ventilator



- Since there is the fan.
- Then pull out the power cable of the fan.
- Remove the 3 fastening screws of the fan.

## Step 5



- Remove the fan where you lift him.

Um das Gerät wieder zusammen zu bauen gehen Sie in umgekehrter Reihenfolge vor.

This document was last generated on 2017-06-19 12:44:00 PM.